

BACKGROUND

Valcor Scientific's chemically inert 2-piece fitting sets offer positive sealing without troubling dead space and are used with standard PTFE tubing.

The 2-piece fitting set incorporates a unique Kel-F nut and Kel-F ferrule arrangement. No flanging or heat tools are required.

| 2-PIECE FITTING | | | | | | | |
|--|-----------|------------|---|-------------------------|--|--|--|
| FITTING SET P/N | PORT SIZE | TUBING P/N | TUBING SIZE (O.D. X I.D.) in. | NO. OF SETS PER PACK | | | |
| SV102P109-10 | #10-32 | | 1/16 X 1/32 | 10 | | | |
| SV102P109-25 | | | | 25 | | | |
| SV102P109-50 | | SVTBGM 109 | | 50 | | | |
| SV252P109-10 | | SVIEGM 109 | | 10 | | | |
| SV252P109-25 | 1/4-28 | | | 25 | | | |
| SV252P109-50 | | | | 50 | | | |
| INTERNAL AND EXTERNAL DIMENSIONS, AS SPECIFIED ABOVE. CUT OFF TUBING WITH A RAZOR BLADE AT AN ANGLE APPROXIMATELY 30.00 FROM AXIS OF TUBING. | | | 30 30 30 30 30 30 30 30 30 30 30 30 30 3 | | | | |
| INSERT ANGLED END OF TUBING BEYOND NUT APPROXIMATELY AS SHOWN. PUSH FERRULE OVER TUBING. | | | | | | | |
| PRESS THE FERRULE INTO NUT. SQUARE-CUT OFF THE ANGLED-END OF TUBE. TUBE IS TO EXTEND 1/16" BEYOND THE FERRULE. | | | | | | | |
| | | | | | | | |

These fittings are to be hand tightened only.





Series Fitting Assembly Instructions

Valcor Scientific

BACKGROUND

Valcor Scientific's chemically inert 3-piece fitting sets offer positive sealing without troubling dead space and are used with standard PTFE tubing.

The 3-piece fitting set incorporates a unique Kel-F nut and Kel-F ferrule arrangement. No flanging or heat tools are required.

| 3-PIECE FITTING | | | | | | | |
|--|-----------------|------------|----------------------------------|-------------------------|--|--|--|
| FITTING SET P/N | PORT SIZE | TUBING P/N | TUBING SIZE (O.D. X I.D.) in. | NO. OF SETS PER PACK | | | |
| SV253P108-10 | | SVTBGM-108 | 0.105 X 1/16 | 10 | | | |
| SV253P108-25 | | | | 25 | | | |
| SV253P108-50 | 414 00 | | | 50 | | | |
| SV253P110-10 | 1/4-28 | SVTBGM-110 | 1/8 X 1/16 | 10 | | | |
| SV253P110-25 | | | | 25 | | | |
| SV253P110-50 | | | | 50 | | | |
| ENSURE TUBING IS OF CORRECT INTERNAL AND EXTERNAL DIMENSIONS, AS SPECIFIED ABOVE. SQUARE-CUT TUBING WITH A RAZOR BLADE. INSERT END OF TUBING BEYOND NUT SLIP CLAMPING RING OVER ASSEMBLY OF NUT & TUBING. | | | | | | | |
| PUSH INSERT U BARBED END C | UNTIL TUBING BO | DTTOMS | | | | | |
| | E THREE PIECES | | | | | | |

These fittings are to be hand tightened only.

